

MODEL Q

Shift Rod and Handle Assembly Instructions

Short Shaft #1235, Long Shaft #1237

The 1990 Johnson/Evinrude 20-30 HP Motors have a design change on the tiller steering models.

The shift handle has been moved from the side of the motor to the front.

Fortunately, the mounting pad for the side shift handle has been left in place.

Attach the metal shift arm for the jet drive reverse mechanism to this mounting pad using 2 – 1/4-20 x 7/8 bolts and square nuts.

Then attach and adjust the shift rod as explained on page 4. (Roller at the end of the cam slot in the forward position for positive lock.

