

INTAKE MOUNTING STUDS  
Large Series #1335AGM

1. Remove as much dirt and grease as possible from the six threaded holes in the main housing.

To install the **M8 x 1.25** studs in the housing, jam the two plain nuts against each other.

(using two wrenches) on the threads to serve as a stud driver.

Put a drop of Loctite on the threads and in the threaded hole. Wind the stud in until it bottoms and then wind in ½ turn more with the wrench.

Free the nuts and repeat on the remaining studs.

2. These stud sets are used on our AGM series jet drives. This kit is only compatible with 4 stroke 35 and 40 horsepower Mercury Factory Jets.
3. All other Large Jets must use a standard 1335 Kit with 5/16 studs.



Specialty Manufacturing Company  
2035 Edison Ave.  
San Leandro, CA 94577  
(510) 562-6049